

How To Operate This Equipment

VOLUME ADJUSTMENT

The sound comes from the Video Projector. Use the REMOTE to adjust the volume.
Plug the RCA audio cable into the Patch panel.
The audio from the Instructors Computer goes straight to the Video Projector.
If you need more volume, an External Amplifier will be needed.

If you want to use the INSTRUCTOR COMPUTER

Turn on the Video Projector by pressing PROJ and ON
Select INSTR PC on the Smart Pad
The Instructor Computer should automatically come up on the screen.

If you want to use an EXTERNAL COMPUTER/LAPTOP

Plug the External Computer VGA into the VGA slot on the Patch Panel.
Turn on the Video Projector by pressing PROJ and ON
Select INSTR PC on the Smart Pad.
Even if the Instructor Computer is on, the Video Projector should display the External Computer automatically.
If this does NOT happen, you will have to tell the computer to output VGA by using the appropriate FUNCTION combination for your computer.
If you unplug the External Computer and the Instructor Computer is still on, the Instructor Computer will automatically appear on the screen again.

If you want to use S-VIDEO (SVHS)

Plug your S-Video/SVHS cable into the video slot on the Patch Panel.
Turn on the Projector by pressing PROJ and ON.
Select PLATE SVHS on the Smart Pad.

If you want to use VIDEO

Plug the RCA cable into the Video slot on the Patch Panel.
Turn on the Video Projector by pressing PROJ and ON.
Select PLATE VID on the Smart Pad.

TO TURN OFF THE EQUIPMENT

Turn off the Video Projector by pressing PROJ and OFF
Wait for the green light to turn red on the Video Projector to ensure the Video Projector is off or until the light in the lens turns off.
The fan will continue to run for 1-3 minutes after turning off the Video Projector.

If having problems call:

2-6993 to reach IMS

Email ims-req@listproc.bgsu.edu for future requests or to report any problems in the class rooms.

